

# PACIFIC STONeworks

## How to Measure for Your Countertop/Project

Follow these steps to take accurate measurements of the countertop space:

- Draw a diagram of your countertop space. In the drawing, don't forget to include the backsplash areas as well.
- On your drawing, make sure to include the spaces for your sink, cooktop, bar sink etc. Some home owners think that sink or cooktop areas need to be excluded from the measurement. But it is not true measurement because the sink or cook top cutouts are done in the entire countertop.
- Use your tape measure to measure the countertop length from *wall to wall* (in inches), not just from one edge of your current countertop to the other.
- Write down the length in the appropriate space on your drawing.
- Measure the depth of the countertops from the wall, but keep in mind, the standard countertop depth is usually 25.5 inches for a granite countertop; this is the common overhang from standard 24-inch cabinets.

After finalizing your project and placed order, our expert technician visits your home to take precise digital measurements of the countertop area before we start cutting.

Sample Countertop Drawing

